



**TOP AND TOP-BOTTOM CLAMPS TO  
PANEL TYPE AND THICKNESS**

PANEL THICKNESS			Monolithic Glass Panels* (using bushings)			Non-Glass Panels (w/o bushings)		
Inches		Metric	Top and Top-Bottom Clamps			Top and Top-Bottom Clamps		
Fractions	Decimal	mm	Small	Medium	Large	Small	Medium	Large
1/16	0.0625	1.59				●		
3/32	0.0938	2.38				●		
1/8	0.1250	3.18				●		
		3.50				●		
5/32	0.1563	3.97	●			●		
		4.00	●			●		
3/16	0.1875	4.76	●			●		
		5.00	●			●		
7/32	0.2188	5.56		●		●		
		6.00		●		●		
1/4	0.2500	6.35		●		●	●	
		7.00			●	●	●	
9/32	0.2813	7.15			●	●	●	
5/16	0.3125	7.94			●		●	
11/32	0.3438	8.73			●			●
		9.53			●			●
3/8	0.3750	10.00			●			●
		10.32			●			●
13/32	0.4063	10.32			●		●	
7/16	0.4375	11.11					●	
15/32	0.4688	11.91						●
		12.00						●
1/2	0.5000	12.70					●	

\* All glass is to be monolithic and tempered.  
Use the supplied bushings when hanging glass panels from Top Clamps or Top-Bottom Clamps.  
This will avoid chipping the glass at mounting holes and potentially breaking the glass panel.

Key  
● Compatible